



Chlorine Standards for Model 1200



For use with the LaMotte 1200 series of chlorine colorimeters. Secondary standards provide a fast way to check calibration without the burden of making primary standards. Based on Standard Methods for the Examination of Water and Wastewater, the operator can calibrate a colorimeter using a permanganate primary standard or a chlorine primary standard. Once the meter is calibrated using the primary standard, the operator can insert secondary standards periodically to evaluate the calibration of the instrument.

- Secondary standard kit contains one blank and three standards for low, mid, and high range chlorine calibrations.
- Packaged a small plastic case with **Certificate of Analysis** stating range of each standard.

Description	Order Code	Price
DPD Chlorine Secondary Standards Kit	4140-02	\$89.75
Standard Chlorine Solution, 250 ppm, 60 mL	6973-H	9.20
Standard Chlorine Solution, 250 ppm, 475 mL	6973-L	25.25
FAS-DPD Titration Kit for chlorine titration	3176-02	77.50
Permanganate Solution, 1000 ppm, 60 mL	3858-H	11.35

Water Testing Leader Since 1919!